



MODEL: Andrea + Gessy

Måleskema - Fitting Chart

Foot size / fodstørrelse	32	33	34	35	36	37	38	39	40	41	42
<b>A: Højde bag / Back height cm</b>											
Normal	34	35	37	39	41	42	43	44	45	46	47
Junior	32	33	35	37	38	39	40	41	42	43	44
<b>B: Lægvidde / Calf size cm</b>											
S	27	27,5	28	30	30,5	31	32	33	34	34,5	35
M	29	29,5	30	32	33	33,5	34	35	36	36,5	37,5
L	31	31,5	32	34	35	35,5	36	37	38	39	40
XL	33	33,5	34	36	37	37,5	38	39	40	41	42

